Mounting Instructions: **DL-300** (LOCK ON LEFT / TOP MOUNTED) CompX 13 minus GAP $\frac{9}{32}$ minus GAP GAP STEP 1 install latch LEFT DOOR . upward view from below OF CABINET TOP OF CABINET STEP 2 13 32 install activator DRILL FOR #6 SCREW **ACTIVATOR** LATCH MECHANISM CENTERED ON DOORS Note: lock shown for reference but not included. Locks sold separately. OF CABINET TOP OF CABINET STEP 3 install catch (1) CATCH **ACTIVATOR** LATCH MECHANISM CENTERED ON DOORS Note: lock shown for reference but not included. Locks sold separately. Reorder #: INS-300

compx.com/instructions

Copyright 2014 © CompX Security Products

(LOCK ON RIGHT / BOTTOM MOUNTED) CompX 13 minus GAP $\frac{9}{32}$ minus GAP GAP STEP 1 install latch RIGHT DOOR OF CABINET Note: lock shown for reference but not included. Locks sold separately. LATCH MECHANISM CENTERED ON DOORS ACTIVATOR STEP 2 DRILL FOR #6 SCREW install activator <u>13</u> 32 BOTTOM OF CABINET OF CABINET Note: lock shown for reference but not included. Locks sold separately. LATCH MECHANISM CENTERED ON DOORS ACTIVATOR STEP 3 CATCH install catch BOTTOM OF CABINET Reorder #: INS-300

compx.com/instructions

Copyright 2014 © CompX Security Products

Mounting Instructions: **DL-300**